

RECORD THIS INFORMATION FOR FUTURE REFERENCE:

Model Number \_\_\_\_\_  
 Serial Number \_\_\_\_\_  
 Date Purchased \_\_\_\_\_

# INSTALLATION INSTRUCTIONS

Self-Contained Unit	
Description	Model
Heat Pump	441004.701
	441004A701

This Unit is designed for OEM installation. All initial installations must be approved by Dometic Corporation.



**Read these instructions carefully. These instructions MUST stay with this product.**

# INTRODUCTION

This heat pump (hereinafter referred to as “unit” or “product”) is designed and intended for installation in a small Recreational Vehicle (hereinafter referred to as RV) during the time it is manufactured. It is recommended that the RV interior space be essentially one undivided space.

Use these instructions to ensure a properly installed, and properly functioning product.

Dometic Corporation reserves the right to modify appearances and specifications without notice.

# TABLE OF CONTENTS

INTRODUCTION .....	2
DOCUMENT SYMBOLS .....	2
IMPORTANT SAFETY INSTRUCTIONS .....	3
A. Recognize Safety Information .....	3
B. Understand Signal Words.....	3
C. Supplemental Directives.....	3
D. General Safety Messages .....	3
GENERAL INFORMATION.....	4
A. Required Tools.....	4
B. Heat Gain .....	4
C. Unit Functions.....	4
D. Condensation .....	4
E. Drain Tube .....	4
F. Heat Pump Operation.....	4
SPECIFICATIONS.....	5
A. Table - Unit Data.....	5
B. Interior Compartment/Sidewall Opening Requirements .....	5
INSTALLATION INSTRUCTIONS .....	6
A. Choosing Proper Location For Unit .....	6
B. Opening Preparation .....	6
C. 120 Vac Wiring Requirements .....	6
D. Low Voltage Wiring Requirements .....	6
E. Choosing Thermostat Location.....	7
F. Installing Unit.....	7
G. Wiring System .....	8
H. Thermostat And Communication Cable Installation.....	8
I. System Checkout .....	8
WIRING DIAGRAM .....	9
A. Unit Wiring Diagram - Earlier Version.....	9
B. Unit Wiring Diagram - Later Version .....	9
INSTALLATION COMPONENTS.....	10

# DOCUMENT SYMBOLS



Indicates additional information that is **NOT** related to physical injury.



Indicates step-by-step instructions.

# IMPORTANT SAFETY INSTRUCTIONS

This manual has safety information and instructions to help you eliminate or reduce the risk of accidents and injuries.

## A. Recognize Safety Information



This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

## B. Understand Signal Words

A signal word will identify safety messages and property damage messages, and will indicate the degree or level of hazard seriousness.

**WARNING** indicates a hazardous situation that, if **NOT** avoided, could result in death or serious injury.

**CAUTION** indicates a hazardous situation that, if **NOT** avoided, could result in minor or moderate injury.

**NOTICE** is used to address practices **NOT** related to physical injury.

## C. Supplemental Directives



Read and follow all safety information and instructions to avoid possible injury or death.

Read and understand these instructions before [installing / using / servicing / performing maintenance on] this product.

Incorrect [installation / operation / servicing / maintaining] of this product can lead to serious injury. Follow all instructions.

The installation **MUST** comply with all applicable local and national codes, including the latest edition of the following standards:

### U.S.A.

- ANSI/NFPA70, National Electrical Code (NEC)
- ANSI/NFPA 1192, Recreational Vehicles Code

### CANADA

- CSA C22.1, Parts I & II, Canadian Electrical Code
- CSA Z240 RV Series, Recreational Vehicles

## D. General Safety Messages

**WARNING** Failure to obey the following warnings could result in death or serious injury:

- This product **MUST** be [installed / serviced] by a qualified service technician.
- Do **NOT** modify this product in any way. Modification can be extremely hazardous.
- Do **NOT** add any devices or accessories to this product except those specifically authorized in writing by Dometic Corporation.

# GENERAL INFORMATION

## A. Required Tools

- Jigsaw
- Electric Drill
- Measuring Tape
- Utility Knife
- Socket Wrench Set
- Phillips Screwdriver / Bit
- Flat-Bladed Screwdriver / Bit
- Sealant
- Drill Bits

## B. Heat Gain

The ability of this air conditioner to maintain the desired inside temperature depends on the heat gain of the RV.

Some preventative measures taken by the occupants of the RV can reduce the heat gain and improve the performance of the air conditioner. During extremely high outdoor temperatures, the heat gain of the RV may be reduced by:

1. Parking the RV in a shaded area
2. Using window shades (blinds and/or curtains)
3. Keeping windows and doors shut or minimizing usage
4. Avoid the use of heat producing appliances
5. Keep return air filter clean

Operation on High Fan/Cooling mode will give optimum or maximum efficiency in high humidity or high outside temperatures.

Starting the air conditioner early in the morning and giving it a “head start” on the expected high outdoor ambient will greatly improve its ability to maintain the desired indoor temperature.

For a more permanent solution to high heat gain, accessories like Dometic outdoor patio and window awnings will reduce heat gain by removing the direct sun. They also add a nice area to enjoy company during the cool of the evening.

## C. Unit Functions

1. Cools and circulates inside air (**Spring/Summer/Fall**).
2. Lowers humidity by removing excess moisture (**Spring/Summer/Fall**).
3. Filters out dust, dirt, and other airborne impurities (**Spring/Summer/Fall/Winter**).
4. Heats and circulates inside air (**Spring/Fall/Winter**).

The unit performs these functions by drawing room air through a filter which traps dust and dirt particles. The air then passes over the indoor conditioning coil which cools and removes excess moisture (**Spring/Summer/Fall**) and heats the air (**Spring/Fall/Winter**). The same air is then returned to the living space to keep you comfortable.

## D. Condensation

The manufacturer of this unit will not be responsible for damage caused by condensation forming on ceilings, windows, or other surfaces. Air contains water vapor which condenses when temperature of a surface is below Dew point. During normal operation this unit is designed to remove a certain amount of moisture from the air, depending on the size of the space being conditioned. Keeping doors and windows closed when this air conditioner is in operation will greatly reduce the chance of condensation forming on interior surfaces.

## E. Drain Tube

1. The drain tube should be left unplugged during heating operation, storage, and any time when traveling after the unit has been operating.

## F. Heat Pump Operation

1. Heat pump mode will not operate when the outside temperature is 30° F and below. If heating is required switch over to furnace mode if applicable.

# SPECIFICATIONS

## A. Table - Unit Data

Model No.	Nominal Capacity (BTU HR) Cooling	Electrical Rating*	Compressor Rated Load Amps	Compressor Locked Rotor Amps	Fan Motor Rated Load Amps	Fan Motor Locked Rotor Amps	Refrigerant R-410A (oz)	Minimum Wire Size**	AC Circuit Protection ****Installer Supplied	Minimum Generator Size*** 1 Unit / 2 Units	Unit Width	Unit Height	Unit Depth	Installed Weight (Pounds)
441004.701	10,150	120 Vac 60 Hz 1 ph	8.9	50.0	2.2	6.6	28.0	12 AWG Copper Up to 24'	20 Amp	2.8 kW / 40 kW	22"	14.5"	20.5"	70
441004A701	10,150		8.9	50.0	2.2	6.6	28.0		20 Amp	2.8 kW / 4.0 kW	22"	14.5"	20.5"	70

\* Maximum unit performance achieved at full rated voltage.

\*\* For wire length over 24 ft., consult the National Electrical Code for proper sizing.

\*\*\* Dometic Corporation gives **GENERAL** guidelines for generator requirements. These guidelines come from experiences people have had in actual applications. When sizing the generator, the total power usage of your RV must be considered. Keep in mind generators lose power at high altitudes and from lack of maintenance.

\*\*\*\* CIRCUIT PROTECTION: Time Delay Fuse or Circuit Breaker Required.

## B. Interior Compartment/Sidewall Opening Requirements

1. A dedicated interior compartment **MUST BE** provided for the unit installation. This compartment **MUST BE OPEN TO THE OUTSIDE AND AIR SEALED TO THE INSIDE**. Interior compartment must be at least 20" deep with an inside cabinet front cutout of 20" x 14". The opening must be 1" above the mounting surface for the unit.
2. A 22-3/4" wide x 15" high opening through the sidewall or outside panel is required.

# INSTALLATION INSTRUCTIONS




## A. Choosing Proper Location For Unit

1. The RV manufacturer engineering staff should carefully review each floor plan to determine the best location before starting an installation.

**i** Alternate configurations and methods may be used which still allow the unit to operate properly; however, these alternate configurations and methods **MUST** be approved by Dometic Corporation.

## B. Opening Preparation

1. **⚠ WARNING FIRE OR ELECTRICAL SHOCK HAZARD.** Verify there are no obstacles inside RV's roof and/or walls (wires, pipes, etc.). Shut **OFF** gas supply, disconnect 120 Vac power from RV, and disconnect positive (+) 12 Vdc terminal from supply battery **BEFORE** drilling or cutting into RV. Failure to obey these warnings could result in death or serious injury.
2. Once the floor plan has been reviewed and the compartment has been selected for unit installation, a 22-3/4" wide by 15" high opening through the sidewall or outside panel is required. The interior compartment must be at least 20" deep. See (FIG. 1) & (FIG. 2).




3. Interior access openings should be prepared as shown. Cabinet front opening must be 20" wide by 14" high to provide an opening for the discharge and return air grille. The opening must be 1" above the mounting surface for the unit. See (FIG. 1).

## C. 120 Vac Wiring Requirements

1. Route a copper, with ground, 120 Vac supply wire from the time delay fuse or circuit breaker to the roof opening. Use a listed/certified non metallic - sheathed single strand cable. See "A. Table - Unit Data" on page (5).
2. Make sure enough supply wire extends into the compartment to ensure an easy connection at the junction box.
3. Protect the wire where it passes into the compartment with approved method.

## D. Low Voltage Wiring Requirements

**i** This unit is wired with a pigtail harness that accepts a plug from a (supplied) pre-made low voltage wire harness. See (FIG. 3) & (FIG. 4).



# INSTALLATION INSTRUCTIONS


1. Route the plug end of the low voltage wire harness to the left front part (viewed from the rear) of the unit compartment, where it can be attached to the unit's pigtail plug. Make sure enough wire extends into the compartment.
2. Route the Red +12 Vdc lead and the Black - 12 Vdc lead from the low voltage wire harness to the convertor location.
3. Route the three conductor thermostat lead from the low voltage wire harness to the Liquid Crystal Display Single Zone (hereinafter referred to as LCD SZ) thermostat mounting location. Make sure 6" of wire extends from the wall at the thermostat mounting location. See "E. Choosing Thermostat Location" on page (7).
4. If system includes a gas furnace, route the two dark Green wires in the low voltage wire harness to the furnace location.


## E. Choosing Thermostat Location


The proper location of the thermostat is very important to ensure that it will provide a comfortable RV temperature. Observe the following rules when selecting a location:



1. Locate the thermostat 54" above the floor.
2. Install the thermostat on a partition, not on an outside wall.
3. **NEVER** expose it to direct heat from lamps, sun or other heat producing items.
4. Avoid locations close to doors that lead outside, windows or adjoining outside walls.
5. Avoid locations close to supply registers and the air from them.

## F. Installing Unit

 Hold-down clamps, screws, drain fitting, and sealant used in step 1 & 2 are in hardware kit 3107662.003 and is purchased separately.

-  1. Now that your compartment is ready with all holes cut, carefully slide the unit into position from the outside. Clip the hold-down clamps over the base pan flange and secure in place with screws. See (FIG. 5).



2. Next, install the drain fittings in the base pan. Sealant must be added around the threaded end of drain fitting before it is screwed into the base pan. See (FIG. 5).
3. Install the rain shield. See (FIG. 9).  
 The rain shield **MUST** have sealant applied to the short flange surfaces and bottom of the unit, sealing the compartment from rainwater and condensation.
4. Seal along the unit bottom to rain shield.
5. Using 1/2" plastic tube, (installer supplied) extend the drain fittings through the vent grille or through holes in the bottom of the compartment. Make sure to seal around the tubing where it exits the bottom of the compartment, and that the condensate will drain to the outside of RV.
6. Make sure the condenser deflector is against the back of the outside grille. This will decrease recirculation of hot air back into the grille. Install the outside grille. See (FIG. 5) & (FIG. 9).
7. The outside work is complete.  
 If your cabinet space is between 20" and 23-1/2" deep, the metal duct extension is **NOT** needed. Attach the registers directly to the unit knockout openings. Do **NOT** insert the registers more than 1/2" into the knockouts. In some installations registers will need to be cut to fit the cabinet space. See "FIG. 9" on page (10) for the order of installation and installation kit component part list.



# INSTALLATION INSTRUCTIONS

- After the registers have been installed, install the inside grille to the cabinet front.

**i** When unit is installed with air distribution ducts to carry the conditioned air to remote areas of the interior space, the ducts **MUST** be sized to maintain a static pressure at the blower outlet between 0.0 and 0.6 inches of water column on high speed.

## G. Wiring System

- 120 Vac Power Supply Connection
  - ⚠ WARNING** ELECTRICAL SHOCK HAZARD. Verify 120 Vac power is disconnected from RV. Failure to obey this warning could result in death or serious injury.
  - ⚠ WARNING** ELECTRICAL SHOCK HAZARD. Provide grounding in compliance with all applicable electrical codes. Failure to obey this warning could result in death or serious injury.
  - Remove junction box cover. See "FIG. 9" on page (10).
  - Route the previously run 120 Vac supply wire through the strain relief and into junction box. Tighten strain relief making sure not to damage wires. Leave enough wire inside junction box to connect to unit 120 Vac wires.
  - Connect the wires in the junction box to the 120 Vac supply wire using appropriate size wire connectors.
    - Active to Black
    - Neutral to White
    - Earth to Green/Yellow
  - Tape the connectors to the supply to ensure they don't vibrate loose.
  - Install junction box cover.

### 2. Low Voltage Wiring Connections

- NOTICE** Verify the positive (+) 12 Vdc terminal is disconnected from supply battery. Otherwise, damage to unit could occur.


**i** The unit has been pre-wired with a 15" pigtail (with plug) that connects to the (supplied) low voltage wire harness for easy connection to the thermostat, 12 Vdc supply, and furnace (if applicable).

- Connect the previously run low voltage wire harness to the unit pigtail. See (FIG. 4) & (FIG. 9).
- Connect the previously run Red wire in the low voltage wire harness to the converter's 12 Vdc positive (+) supply terminal.
- Connect the previously run Black wire in the low voltage wire harness to the converter's 12 Vdc negative (-) supply terminal.

- Connect the previously run (2) Dark Green wires in the low voltage wire harness to the furnace (if applicable) thermostat connections. The polarity of this connection does not matter.

## H. Thermostat And Communication Cable Installation

- Remove the cover from the LCD SZ thermostat. Depress tab on bottom of thermostat and separate it from the base.
- Insert the 3 thermostat wires from the low voltage wire harness through the hole in base assembly.
- Mount the thermostat level on the wall using the screws provided.
- Make the following connections to the thermostat. See (FIG. 6).



- Red/White wire to the 12V+ terminal
  - Blue wire to the 12V- terminal
  - Orange wire to the "COMMS" terminal
- Inspect all connections to make sure they are tight and not touching any other terminals or wires.
  - Push the wires back through the base into the wall. Place cover on the thermostat and push until an audible click is heard.
  - This completes the unit installation.

## I. System Checkout


- Verify that all features of the system work. See the LCD SZ thermostat Operating Instructions or User's Guide. Reconnect the 12Vdc and 120 Vac power supplies. Check fan speeds, cooling mode, heating mode, and furnace mode (if connected) operation.

If features do not work, disconnect the 120 Vac and 12 Vdc power supplies and verify that all wiring is correct.




# WIRING DIAGRAM

## A. Unit Wiring Diagram - Earlier Version



## B. Unit Wiring Diagram - Later Version



# INSTALLATION COMPONENTS

FIG. 9

