



DETECTION RANGE

16




17



SETTING

18



19



20 MWE9104

		Min ... Max	Factory
01		00 01 02	02
02		01 02 FRONT REAR ON ON	02
07		00, 01 ... 05 OFF, 1 ... 5 s	05 5 s
08		01 ... 99 1/s - 99/s	03 3/s
18		00, 01 OFF, ON	00 OFF
40		02, 03, 04 2, 3, 4 sensors	04
47		00 01 02	00
42		00 ... 01 L R / R L	00 L R
43		-9 ... +9	00
45		12 ... 18 120 - 180 cm	16 160 cm

		Min ... Max	Factory
46		45 ... 90 45 - 90 cm	65 65 cm
47		30 ... 12 30 - 120 cm	35 35 cm
48		30 ... 90 30 - 90 cm	35 35 cm
49		00 = OFF 05, 10, 15, 20, 25, 30 = cm 99 = AUTO	00
54		01 = 1s 02 = 3 - 10 s 99 = constant	99
55		00 ... 01 AUTO	00
57		00, 01 ... 30 OFF, 1 ... 30 s	00
60		00 ... 01 <input checked="" type="checkbox"/> <input checked="" type="checkbox"/>	00 <input checked="" type="checkbox"/>
61		10 ... 13 100 - 130 cm	10 100 cm
62		10 ... 13 100 - 130 cm	10 100 cm

21 MWE9104F

		Min ... Max	Factory
01		00 01 02	02
02		01 02 FRONT REAR ON ON	01
07		00, 01 ... 05 OFF, 1 ... 5 s	05 5 s
08		01 ... 99 1/s - 99/s	03 3/s
09		00 ... 09 0,0/s - 0,9/s	00 0,0/s
18		00, 01 OFF, ON	01 ON
20		02, 03, 04 2, 3, 4 sensors	04
21		00 01 02	00
22		00 ... 01 L R / R L	00 L R

		Min ... Max	Factory
23		-9 ... +9	00
25		45 ... 12 45 - 120 cm	85 85 cm
26		45 ... 90 45 - 90 cm	60 60 cm
27		30 ... 50 30 - 50 cm	35 35 cm
28		30 ... 50 30 - 120 cm	35 35 cm
29		00 = OFF 05, 10, 15, 20, 25, 30 = cm 99 = AUTO	00
34		01 = 1s 02 = 3 - 10 s 99 = constant	01
36		00 ... 01 ON	00
37		00 = OFF 10, 20 ... 60 0, 20 - 60 s	20 20 s



YOUR LOCAL DEALER
dometic.com/dealer

YOUR LOCAL SUPPORT
dometic.com/contact

YOUR LOCAL SALES OFFICE
dometic.com/sales-offices

A complete list of Dometic companies, which comprise the Dometic Group, can be found in the public filings of:
DOMETIC GROUP AB Hemvärnsgatan 15 SE-17154 Solna Sweden

