Customer service

There is a strong, worldwide network to assist in servicing and maintaining your sanitation system. For the Authorized Service Center near vou, please call from 8:00 a.m. to 5:00 p.m. (ET) Monday through Friday.

You may also contact or have your local dealer contact the Parts Distributor nearest you for quick response to your replacement parts needs. They carry a complete inventory for the Dometic product line.

Telephone: 1 800-321-9886 U.S.A. and Canada

330-439-5550

International

330-496-3097 Fax:


U.S.A. and Canada

330-439-5567 International

Web site: http://www.Dometic.com



Dometic Corporation, Sanitation Division 13128 State Rt. 226, P.O. Box 38 Big Prairie, OH 44611 USA 1-800-321-9886 • Fax: 330-496-3097 www Dometic com



REVISION A Form No. 600346874 9/17 ©2017 Dometic Corporation

VacuFlush® Toilet System Quick-Start Guide

VacuFlush toilet with foot pedal

Toilet system start-up

- 1. Fill freshwater tank.
- 2. Turn on electrical power and water supply to toilet.
- 3. Flush water into toilet system by pressing foot pedal until water starts flowing to the vacuum pump, about 15 seconds. The vacuum pump will run about one minute until system reaches operating vacuum level and then will shut off.

Normal toilet operation

ADD WATER TO TOILET BOWL



Raise foot pedal until desired water level is reached. More water is usually added only when flushing solids. (If pedal is pressed too long, water may overflow the toilet bowl.)

FLUSH TOILET

Press foot pedal sharply down until contents clear bowl. (A popping noise is normal when the vacuum seal is broken.) Hold foot pedal for three seconds. After flush, let foot pedal snap back into position. If foot pedal is accidentally released before waste clears bowl, do not flush again until vacuum pump stops running. A small amount of water remains in bowl after flushing.

For system with VacuFlush status panel, flush only when the green "OK to Flush" light is on. Toilet will not flush until the green light is on. It takes about one minute for vacuum to recharge for the next flush.

If the red "Do Not Flush" light is on, the system is either recharging the vacuum, or the holding tank is full. Do not attempt to flush the toilet during these conditions, or a clog may occur in the toilet system.

VacuFlush toilet with electric flush switch

Toilet system start-up

- 1. Fill freshwater tank.
- 2. Turn on electrical power and water supply to toilet.
- Flush water through entire toilet system by flushing toilet five times (press Flush switch and allow each flush cycle to complete until green light indicates system is ready for next flush). Each cycle takes about one minute.

Normal toilet operation

ADD WATER TO TOILET BOWL



Press "Add Water" switch until desired water level is achieved. More water is usually added only when flushing solids. (If switch is pressed too long, water flow will shut off automatically to avoid overflow.)

FLUSH TOILET



Press "Flush" switch down for a moment, then release it. Flush only when the green "OK to Flush" light is on. Toilet will not flush until the green "OK to Flush" light is on.

It takes about one minute for vacuum to recharge for the next flush.

If the red "Do Not Flush" light is on, the system is either recharging the vacuum, or the holding tank is full. Do not attempt to flush the toilet

during these conditions, or a clog may occur in the toilet system.

DO NOT FLUSH FOREIGN OBJECTS



CAUTION! Flush only water, bodily wastes and rapid-dissolving tissue paper. Do not flush wet wipes, sanitary napkins, condoms, diapers, razor blades paper cups, cotton swabs food, hair or liquids such as oils or solvents. Clogging or damage to the toilet system may occur.



Note

Make sure all guests understand toilet operation before use.

