

MagicSpeed CBI200 Application & Functionality: 03-2017 SW:14-30

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
Alfa Romeo							
	Baris - 2008		YES	YES	YES	CAN HIGH - R 6 PINK-BLACK CAN LOW - N 5 PINK-WHITE	Connector BLUE 36 pin (grey) split at rear of fuse box. Position (R and L) Nr. 6 and Nr. 5.
	Giulietta - 2010		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and Nr. 2.
	GT - 2004		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connector BLUE (red retention), 40-pin mated G on front of fuse box to left of steering wheel. Position (R and L) Nr. 21 and Nr. 2.
	Mio - 2008		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and Nr. 2.
	147		YES	YES	YES	CAN HIGH PINK-BLACK CAN LOW PINK-WHITE	Connector BLUE (red retention), 40-pin mated G on front of fuse box to left of steering wheel. Position (R and L) Nr. 21 and Nr. 2.
	159 - 2006		YES	YES	YES	CAN HIGH PINK-BLACK CAN LOW PINK-WHITE	Connector BLUE 36 pin (grey) split at rear of fuse box. Position (R and L) Nr. 6 and Nr. 5.
Aston Martin							
	Vantage - 2008		YES	YES	YES	CAN H + RED / BROWN CAN L + RED / BLACK	The CAN wiring is located at the Body Diagnostic socket, drivers side, bottom of the dash panel. There are 4 diagnostic sockets named Body & C8D.
	DB9 - 2006		YES	YES	YES	CAN H + Pin 3 CAN L 0 + Pin 11	The CAN wiring is located at the C8D socket, drivers side, bottom of the dash panel.
Audi							
	A1 - 2010		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L) Nr. 13 and Nr. 16.
	A3 - 2002		YES	YES	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	Connector 12 pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side. Position (R and L) Nr. 8 and Nr. 7.
	A3 - 2010		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L) Nr. 13 and Nr. 16.
	A3 - 2013		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BLACK 73 pin the connector is located the lower drivers side under panel Position (R and L) Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	A4 - 2002		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L) Nr. 13 and Nr. 12.
	A4 - 2005		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L) Nr. 13 and Nr. 12.
	A4 - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A4 - 2015	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A5 - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A5 - 2016	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A6 - 2002		YES	(YES)	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	The interface is installed to the CAN wiring at the audio connector. Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A6 - 2011		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A7 - 2011		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A8 - 2003		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A8 - 2011		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	Q3 - 2011		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L) Nr. 13 and Nr. 16.
	Q5 - 2008		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	Q5 - 2017	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	Q7 - 2008		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	Q7 - 2015	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	R8 - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector 12 pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side.
	S5 - 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top rear clutch pedal. Pos. (R and L) Nr. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	S6 - 2003		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW ORANGE BROWN	Connector GRE VIOLET 35 pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (R and L) Nr. 13 and Nr. 12.
	TT - 2002		YES	YES	YES	CAN HIGH ORANGE-PURPLE CAN LOW ORANGE BROWN	The interface is installed to the CAN wiring at the audio connector.
	TT - 2007		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L) Nr. 13 and Nr. 16.
	TT - 2014	NEW	YES	(YES)	YES	CAN H + ORANGE / GREEN CAN L 0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (R and L) Nr. 13 and Nr. 16.
BMW							
	1 Series(E81) (E86) 2005		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector BLACK GREY 51 pin connected to light electronic module behind the kick plate, driver's side. Position (R and L) Nr. 48 and Nr. 45.
	1 Series(F20) (F21) 2012		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module) near the 'A' pillar. The CAN BUS wiring is a twisted pair of wires. Connector: WHITE 54 pins Position (R and L) Nr. 34 and Nr. 33.
	2 Series(F20) (F46) 2014	NEW	YES	(YES)	YES	CAN HIGH BLUE-RED CAN LOW RED	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L) Nr. 34 and Nr. 33.
	3 Series(E46) 2002		YES	YES	YES	CAN H YELLOW-BLACK CAN L 0 YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.
	3 Series(E90) 2005		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Remove the vehicle speedometer assembly, the CAN wires are located at the connector plug. The CAN wiring can also be located at the audio unit Dashboard. The CAN bus wiring is a twisted pair of wires.
	3 Series(F30) 2012		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module) near the 'A' pillar. The CAN BUS wiring is a twisted pair of wires. Connector: WHITE 54 pins Position (R and L) Nr. 34 and Nr. 33.
	5 Series(E60) 2003		YES	(YES)	YES	CAN H BLACK CAN L 0 YELLOW	Connector BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L) Nr. 35 and Nr. 26.
	5 Series(F10) (F11) 2013		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	6 Series(E63) 2004		YES	(YES)	YES	CAN H BLACK CAN L 0 YELLOW	Connector WHITE. Re-pin connected to the black electronic module "CAS", fastened to the left of steering column. Position (R and L) Nr. 14 and Nr. 33.
	6 Series(F12) 2011	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	7 Series(F51) 2008	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	X1 (E84) 2009		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector BLACK GREY 51 pin connected to light electronic module behind the kick plate, driver's side. Position (R and L) Nr. 48 and Nr. 45.
	X1 (F46) 2015	NEW	YES	(YES)	YES	CAN HIGH BLUE-RED CAN LOW RED	Remove the lower passenger under glove box trim, locate the FEM (Forward Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L) Nr. 34 and Nr. 33.
	X3 (E46) 2003		YES	YES	YES	CAN H YELLOW-BLACK CAN L 0 YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector White 12 pins behind the glove compartment passenger side. Position (R and L) Nr. 5 and Nr. 6.
	X3 (F25) 2011		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module, fastened to the left of the steering column.
	X4 (F26) 2014	NEW	YES	YES	YES	CAN H YELLOW-BLACK CAN L 0 YELLOW-BROWN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	X5 (E33) 2006		YES	YES	YES	CAN H YELLOW-BLACK CAN L 0 YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector White 12 pins behind the glove compartment passenger side.
	X5 (E70) 2007		YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L) Nr. 35 and Nr. 26.
	X5 (F15) 2013	NEW	YES	(YES)	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	X6 (E71) 2008		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector BLACK 41 pin connected to white electronic module "CAS", fastened to the left of steering column. Position (R and L) Nr. 35 and Nr. 26.
	X6 (F16) 2014	NEW	YES	YES	YES	CAN HIGH ORANGE-GREEN CAN LOW GREEN	Connector LIGHT BLUE (black retention) connected to electronic module (aluminium case), fastened to the left of the steering column.
	Z4 (E40) 2003		YES	YES	YES	CAN H YELLOW-BLACK CAN L 0 YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.
Cadillac							
	Escalade - 2006		YES	YES	YES	CAN H BEIGE-BLACK PIN 6 CAN L 0 BEIGE PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
Chevrolet							
	Aveo - 2011		YES	(YES)	YES	CAN HIGH PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and G.N.D.
	Camaro - 2009		YES	(YES)	YES	CAN H BROWN-BLACK PIN 6 CAN L 0 BROWN-BLACK PIN 8	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 Green and G.N.D.)
	Captiva - 2007 (2011)		YES	(YES)	YES	CAN H BROWN-BLACK PIN 6 CAN L 0 BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
	Coselco - 2007		YES	YES	YES	CAN HIGH ORANGE PIN 1 CAN LOW BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
	Cruze - 2010		YES	(YES)	YES	CAN LOW GND CAN HIGH BROWN-BLACK PIN 6	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and G.N.D.
	Equinox - 2006		YES	YES	YES	CAN HIGH BROWN PIN 6 CAN LOW BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
	HRV - 2006		YES	(YES)	YES	CAN HIGH PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and G.N.D.
	Malibu - 2004		YES	(YES)	YES	CAN H PIN 6 CAN L 0 PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
	Onix - 2010		YES	(YES)	YES	CAN HIGH GREEN PIN 1 CAN LOW GND	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 1 and G.N.D.
	Spark - 2010		YES	(YES)	YES	CAN H BROWN-BLACK PIN 6 CAN L 0 BROWN PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
	Volt - 2011		YES	(YES)	YES	CAN H PIN 6 CAN L 0 PIN 14	Connected to connector C8D on left underneath steering column. Position (R and L) Nr. 8 and No. 14, or (No. 1 and G.N.D.)
Chrysler							
	300C		YES	(YES)	YES	CAN H + WHITE / ORANGE CAN L + WHITE / RED	The CAN wiring is located at the radio wiring connector. Remove the dash face panel (striped) and install the radio for access.
	300C - 2011		YES	(YES)	YES	CAN H + GREEN CAN L 0 + WHITE	The CAN wiring is located at the radio wiring connector. Remove the dash face panel (striped) and install the radio for access. The CAN wiring cannot be tested at the shop.

MagicSpeed CB1200 Application & Functionality: 03-2017 SW-14-30

Manufacturer	Modell	Note	Speed	Ignition	Reverse	Wire connections	Position
Caterpillar							
Bellgrove	2008		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14 or (Pin. 10, No. 13, near at the audio Quadlock) Position 01 and L3, No. 8 and No. 14 or (Pin. 10, No. 13, near at the audio Quadlock)
C2	2006		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C3	2002		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C3	2009		YES	YES	YES	CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C3	2016	NEW	YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C4	2005		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C4	2010	NEW	YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
C4 Cabrio	2014		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
CS	2002		YES	YES	YES	CAN H + WHITE CAN L0 + PURPLE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires, colored as below. Orange CAN L0 wiring is located in a wiring loom, behind driver side dash. The CAN bus wiring is a twisted pair of wires, colored as below.
C-Crowler	2003		YES	YES	YES	CAN H + GREEN (behind speedometer)- ORANGE CAN L0 + PINK (behind speedometer)- WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector WHITE 20-Pin behind the radio. CAN HIGH No. 8 ORANGE and CAN LOW No. 18 WHITE
Jiminy-Dipatch	2007		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
Jiminy-Dipatch	2016	NEW	YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
Juniper	2011		YES	YES	YES	CAN HIGH PIN 1 BLACK/ORANGE CAN LOW PIN 13 WHITE/ORANGE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Juniper Euro 6	2014	NEW	YES	YES	YES	CAN HIGH PIN 1 BLACK/ORANGE CAN LOW PIN 13 WHITE/ORANGE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
DB3	2010		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
DB4	2011		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
DB5	2012		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
Nemo	2008		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Picasso	2005		YES	YES	YES	CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
Dacia							
Duster	2010		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Loggy	2012		YES	YES	YES	CAN H + WHITE CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Bandux	2012	NEW	YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Daihatsu							
Tanto	2011		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Dodge							
Caliber	2007		YES	YES	YES	CAN H + WHITE / ORANGE CAN L0 + WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
Calaver	2009		YES	YES	YES	CAN H + WHITE / ORANGE CAN L0 + WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
Challenger	2011		YES	YES	YES	CAN H + GREEN CAN L0 + WHITE	The CAN wiring is located at the LCD screen connector. Also located in the main loom behind the drivers side lower dash kick panel.
Charger	2009		YES	YES	YES	CAN H + WHITE / ORANGE CAN L0 + WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
Durango	2009		YES	YES	YES	CAN H + WHITE / ORANGE CAN L0 + WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
RAM	2009		YES	YES	YES	CAN H + WHITE / ORANGE CAN L0 + WHITE / ORANGE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
Fiat							
Bravo	2007		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connector BLUE 35 pin (green part) at rear of fuse box. Position 01 and L3, No. 8 and No. 14
Doblo	2001		YES	YES	YES	CAN HIGH GRAY / BLACK CAN LOW WHITE / GREEN	The CAN wiring is located at the radio wiring ISO connector. Position 01 and L3, No. 1 and No. 3.
Doblo	2011 >		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Ducato	2002		YES	YES	YES	CAN HIGH PIN 6 CAN LOW PIN 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Ducato	2007		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connector BLUE 35 pin (green part) at rear of fuse box. Position 01 and L3, No. 8 and No. 14
Ducato Euro 6	2011		YES	YES	YES	CAN HIGH PIN 1 BLACK/ORANGE CAN LOW PIN 13 WHITE/ORANGE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Ducato Euro 6	2014	NEW	YES	YES	YES	CAN HIGH PIN 1 BLACK/ORANGE CAN LOW PIN 13 WHITE/ORANGE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Fianino	2008		YES	YES	YES	CAN HIGH PIN 1 BLACK/ORANGE CAN LOW PINK / WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14, Or, No. 1 BLUE and No. 9 WHITE
Fianino	2011		YES	YES	YES	CAN HIGH PIN 1 GREY CAN LOW PIN 11 WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Grande Punto / EVO	2008		YES	YES	YES	CAN HIGH PIN 6 CAN LOW PIN 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14, Or, No. 1 BLUE and No. 9 WHITE
Panda	2002		YES	YES	YES	CAN HIGH PINK / WHITE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14, Or, No. 1 BLUE and No. 9 WHITE
Panda	2012	NEW	YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14, Or, No. 1 BLUE and No. 9 WHITE
Punto	2003		YES	YES	YES	CAN HIGH PIN 1 BLACK CAN LOW PINK / WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 27 and No. 28
Scout	2007		YES	YES	YES	CAN H + Pin 10 CAN L0 + Pin 13	Connecting to position No. 10 and No. 13, near at the audio quadlock connector (Position 01 and L3, No. 8 and No. 14 on OBDII connector only for speed signal)
Silo	2002		YES	YES	YES	CAN HIGH PIN 6 CAN LOW PINK / WHITE	Connector BLACK 32 pin on left underneath steering column on fuse box. Position 01 and L3, No. 28 and No. 10
Talento	2014	NEW	YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14
Tipo	2015	NEW	YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
500	2007		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
500L	2013		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
500X	2014	NEW	YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14
Ford							
B Max	2012		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
C Max	2011		YES	YES	YES	CAN H + Pin 11 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
ECOSPORT	2013		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
F-150	2006		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
F-250	2006		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
F-350	2006		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
F-350	2010		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
F-350	2016		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Fiesta	2008		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Fiesta	2004		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Fiesta	2008 (2011)		YES	NO	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Fiesta	2013		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Focus CMax	2003		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Focus CMax	2009		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Focus	2005		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Focus	2011		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Focus (USA)	2005		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Fusion	2004		YES	YES	YES	CAN H + GREY / RED CAN L0 + BLUE / RED	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 6 and No. 14
Fusion (USA)	2010		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Galaxy	2006		YES	YES	YES	CAN H + ORANGE / BLACK or ORANGE / GREEN CAN L0 + ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. The CAN wiring is a twisted pair. Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, colored as below.
Galaxy	2016	NEW	YES	YES	YES	CAN H + WHITE / BLUE CAN L0 + WHITE	The CAN wires are located at the BLACK OBD connector 24 PINS located left underneath steering column. PIN 20 CAN HIGH PIN 19 CAN LOW. Or CAN H GREY/ORANGE and CAN L0 PURPLE/ORANGE
Ka	2008		YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Ka	2016	NEW	YES	YES	YES	CAN HIGH BLUE CAN LOW WHITE	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 1 and No. 9, Or, No. 6 and No. 14
Kuga	2009		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11, Or, No. 9 and No. 10 near at the audio Quadlock
Kuga	2013		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Mandev	2002		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Mandev	2007		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Mandev	2015	NEW	YES	YES	YES	CAN H + Pin 20 WHITE / BLUE CAN L0 + Pin 19 WHITE	The CAN wires are located at the BLACK OBD connector 24 PINS located left underneath steering column. PIN 20 CAN HIGH PIN 19 CAN LOW. Or CAN H GREY/ORANGE and CAN L0 PURPLE/ORANGE
Masung	2005		YES	YES	YES	CAN H + WHITE / RED CAN L0 + PINK / RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, colored as below.
Masung	2011	NEW	YES	YES	YES	CAN H + WHITE / RED CAN L0 + PINK / RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, colored as below.
Range	2012		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14
Range	2016	NEW	YES	YES	YES	CAN H + WHITE / BLUE CAN L0 + WHITE	The CAN wires are located at the BLACK OBD connector 24 PINS located left underneath steering column. PIN 20 CAN HIGH PIN 19 CAN LOW. Or CAN H GREY/ORANGE and CAN L0 PURPLE/ORANGE
Transit	2006		YES	YES	YES	CAN H + Pin 8 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14, Or, No. 9 and No. 10 near at the audio Quadlock
Transit	2013	NEW	YES	YES	YES	CAN H + Pin 14 CAN L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 8 and No. 14, Or, No. 9 and No. 10 near at the audio Quadlock
Transit Euro 6	2016	NEW	YES	YES	YES	CAN H + Pin 20 WHITE / BLUE CAN L0 + Pin 19 WHITE	The CAN wires are located at the BLACK OBD connector 24 PINS located left underneath steering column. PIN 20 CAN HIGH PIN 19 CAN LOW. Or CAN H GREY/ORANGE and CAN L0 PURPLE/ORANGE
Transit Connect	2007		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Transit Connect	2014		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Transit Custom	2013		YES	YES	YES	CAN H + Pin 3 CAN L0 + Pin 11	Connected to connector OBD on left underneath steering column. Position 01 and L3, No. 3 and No. 11
Transit Custom Euro 6	2016	NEW	YES	YES	YES	CAN H + Pin 20 WHITE / BLUE CAN L0 + Pin 19 WHITE	The CAN wires are located at the BLACK OBD connector 24 PINS located left underneath steering column. PIN 20 CAN HIGH PIN 19 CAN LOW. Or CAN H GREY/ORANGE and CAN L0 PURPLE/ORANGE

MagicSpeed CBI200 Application & Functionality: 03-2017 SW:14-30

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
Leviss							
	H200 - 2006		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	rs 390 - 2009		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	rs 4004 - 2009		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
Maserati							
	Gran Turismo 2007		YES	YES	YES	CAN HIGH: N.6 PINK-BLACK CAN LOW: N.5 PINK-WHITE	Connector BLUE 36 pin (green part) at rear of fuse box. Position (R and L) No. 5 and No. 6.
Mazda							
	2 - 2003		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	2 - 2007	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	2 - 2014	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	3 - 2004		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	3 - 2014		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	5 - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	5 - 2010		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	6 - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	6 - 2012	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CK3 - 2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CK5 - 2012		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CK7 - 2006		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	CK9 - 2007		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Demio - 2005		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MPV - 2004		YES	YES	YES	CAN H + Pin 6 - BLUE / WHITE CAN LO - Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MX5 - 2006		YES	YES	YES	CAN H + Pin 6 - BLUE / WHITE CAN LO - Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	MX6 - 2004		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
Mercedes							
	A - Class W168 - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires. Connected in the door frame behind the kick plate, passenger's side or driver's side.
	A - Class W169 - 2006		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN bus wiring is a twisted pair of wires.
	A - Class W176 - 2012		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side airloom (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
	B - Class W245 - 2005		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	B - Class W246 - 2011		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	C - Class W203 - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - GREEN	Remove the lower drivers side under panel. Locate the ignition barrel (turn or control unit). The CAN bus wiring is a twisted pair of wires.
	C - Class W204 - 2007	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	The wiring is located in the main loom behind the driver's side lower dash kick panel. The Reverse Gear output is only available on Automatic vehicles.
	C - Class W205 - 2013	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	The wiring is located in the main loom behind the driver's side lower dash kick panel. The Reverse Gear output is only available on Automatic vehicles.
	CL - 2007	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLK - 2002		YES	YES	YES	CAN H + BROWN / RED CAN LO + BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	CLA W117 - 2013	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO + BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	CLS - 2007		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLS W218 - 2011	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	E - Class W211 - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	E - Class W212 - 2009	Reverse only with auto gearbox	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	E - Class W213 - 2012	NEW	YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	G - Class - 2009		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	GLA - Class - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	GLE - Class Coupe - 2015	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	GLK - Class - 2008	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	GLS - Class - 2008	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	M - Class - 1999		YES	YES	YES	CAN H + WHITE CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at the control module. The CAN bus wiring is a twisted pair of wires.
	M - Class - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Connected in the CANbus concentrator connector wires, behind the kick plate, passenger's side. The CAN bus wiring is a twisted pair of wires.
	M - Class W168 - 2011		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Connected in the CANbus concentrator connector wires, behind the kick plate, passenger's side. The CAN bus wiring is a twisted pair of wires.
	R - Class - 2006		YES	YES	(A/UT/O)	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower passenger side under panel. The CANbus wires are located in concentrator connector block. The CAN bus wiring is a twisted pair of wires.
	S - Class - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located on the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	S - Class W221 - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	S - Class W222 - 2013		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SL - Class - 2001		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SL - Class - 2012	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SLK - 2004		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	SLK - 2011	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CANbus junction connector. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2000		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - BROWN	Remove the vehicle speedometer cover. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2008		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	Sprinter - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	V-Class - 2014	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vaneo - 2000		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vito - 2004		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vito - 2015	NEW	YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Viano - 2003		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
Mercedes Truck							
	Actros 2003		YES	YES	YES	CAN H + GREEN/WHITE CAN LO - GREEN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Actro		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	Connected in the door frame behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	Axor		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side airloom (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
	Econic H - 2007		YES	YES	YES	CAN H + BROWN / RED CAN LO - BROWN	The CAN wires are at the socket unit and in the driver's side airloom (B Way Black Connector). The CAN bus wiring is a twisted pair of wires.
Mini							
	Mini - 2001		YES	YES	YES	CAN H + YELLOW / BLACK CAN LO + YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Mini - 2007		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN LO - GREEN	Connector BLACK/DORARY 51 pin connector is located on the light control unit behind the driver side lower dash kick panel. Position (R and L) No. 46 and No. 45.
	Mini - 2014	NEW	YES	(YES)	YES	CAN HIGH: BLUE-RED CAN LOW: RED	Remove the lower passenger under glove box trim. Inside the FEM (Fused Electrical Module). The CAN BUS wiring is a twisted pair of wires. Connector: 12 pins WHITE Number 10. Position (R and L).
	Coastman - 2010		YES	(YES)	YES	CAN H + Pin 26 ORANGE / GREEN CAN LO + Pin 13 GREEN	Connector BLACK 52 pin connector is located in the junction box on the right side passenger glove compartment. Position (R and L) No. 26 and No. 13.
Mitsubishi							
	ASX - 2010		YES	YES	YES	CAN H + BLACK CAN LO WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Cali - 2005		YES	YES	YES	CAN H + BROWN / RED CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	L200 Evo 10 - 2008		YES	YES	YES	CAN H + GREEN CAN LO - PINK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	L200 - 2012		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	L200 - 2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Grandis - 2004		YES	YES	YES	CAN H + Pin 6 - Pin 4 - RED / BLUE CAN LO + Pin 14 - Pin 3 - BLACK / BLUE	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Outlander - 2007		YES	YES	YES	CAN H + GREEN (behind speedometer) - ORANGE CAN LO - PINK (behind speedometer) - WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector WHITE 20-Pin behind the radio. CAN HIGH No. 8 ORANGE and CAN LOW No. 18 WHITE.
	Outlander - 2013		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.
	Space Star - 2013		YES	YES	YES	CAN H + Pin 6 CAN LO - Pin 14	Connected to connector OBD on left underneath steering column. Position (R and L) No. 6 and No. 14.

MagicSpeed CB1200 Application & Functionality: 03-2017 SW:14-30

Manufacturer	Modell	Note	Speed	Ignition	Reverse	Wire connections	Position
Nissan							
Almera - 2002			YES	YES	YES	CAN H = BLUE CAN LO = RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, colored as follows:
Almera - 2007		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Clio - All Models			YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Elgrand - 2002			YES	YES	YES	CAN H = Pin 6 - Pin 4 - PINK CAN LO = Pin 5 - BLUE	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Leaf - 2011	NEW	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Missia - 2003		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Missia - 2010	NEW	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Mustang - 2004 (L-2010) eng.	Only for gasoline eng.	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
June - 2010		YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Navara - 2006		YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Navara - 2014	NEW	YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Note - 2005		YES	YES	YES	YES	CAN H = BLUE CAN LO = YELLOW	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Note - 2012	NEW	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
NISSAN - 2010	NEW	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Pathfinder - 2008		YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Pathfinder - 2012	NEW	YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Path - 2009		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Primastar - 2014	NEW	YES	YES	YES	YES	CAN H = BLUE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Primastar - 2002		YES	YES	YES	YES	CAN H = BLUE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Qashqai - 2008	Only for diesel	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Qashqai - 2013	NEW	YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Rogue - 2008		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Sansa - 2008		YES	YES	YES	YES	CAN H = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Skania - 2003		YES	YES	YES	YES	CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
X-Trail - All Models		YES	YES	YES	YES	CAN LO = WHITE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
X-Trail - 2014	NEW	YES	YES	YES	YES	CAN H = WHITE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
350Z - 370Z - 2003		YES	YES	YES	YES	CAN H = F CAN LO = 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Opel							
Adam - 2014	NEW	YES	YES	YES	YES	CAN H = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Agila - 2009		YES	YES	YES	YES	CAN H = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Ampere - 2011		YES	YES	YES	YES	CAN H = BROWN/BLACK CAN LO = BROWN	The CAN wiring is located at the OBD socket, under the drivers side dash. Position (H and L) No. 6 and No. 14
Ampere - 2007		YES	YES	YES	YES	CAN H = BROWN/BLACK CAN LO = BROWN	The CAN wiring is located at the OBD socket, under the drivers side dash. Position (H and L) No. 6 and No. 14
Astra H - 2014		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connector GRN-BLACK 12/27-PIN connected behind the kick plate, driver's side. Position (H and L) No. 6 and No. 14. Or Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14.
Astra J - 2010		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connector BLUE 27-PIN connected underneath car radio. Position (H and L) No. 22 Or Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14.
Astra K - 2016		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connector BLUE 27-PIN connected underneath car radio. Position (H and L) No. 22 Or Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14.
Combo - Combo - 2001		YES	YES	YES	YES	CAN LO = WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires.
Combo - 2012		YES	YES	YES	YES	CAN LO = Pin 14 CAN LO = GREEN	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Combo - 2008		YES	YES	YES	YES	CAN LO = WHITE	The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Combo - 2015	NEW	YES	YES	YES	YES	CAN H = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Insignia - 2009	YES	YES	YES	YES	YES	CAN LO = CONNECT TO GROUND	Position (H and L) No. 1 and G.N.D. Or Position (H and L) No. 6 and No. 14.
Insignia - 2014		YES	YES	YES	YES	CAN H = GREEN CAN LO = WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Insignia - 2010		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	The CAN wiring is located at the OBD socket, near the center console under the gearchange lever. Position (H and L) No. 6 and No. 14.
Insignia - 2012		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L) No. 1 and G.N.D. Or Position (H and L) No. 6 and No. 14.
Insignia - 2003		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Insignia - 2009		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connector GRN-BLACK 12/27-PIN connected behind the kick plate, driver's side. Position (H and L) No. 97. Or connector OBD underneath car radio. Position (H and L) No. 6 and No. 14.
Insignia - 2004		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14
Insignia - 2005		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14
Insignia - 2003		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14
Insignia - 2005		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connector GRN-BLACK 12/27-PIN connected behind the kick plate, driver's side. Position (H and L) No. 50. Or Connected to connector OBD underneath car radio. Position (H and L) No. 6 and No. 14.
Insignia - 2012		YES	YES	YES	YES	CAN H = GREEN CAN LO = CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L) No. 1 and G.N.D. Or Position (H and L) No. 6 and No. 14.
Insignia - 2007		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14
Peugeot							
207 - 2006		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
208 - 2012		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
207 - 2001		YES	YES	YES	YES	CAN H = GREEN CAN LO = GREY	Remove the lower passenger side under panel. The CAN wires are located at the BSI module. The CAN bus wiring is a twisted pair of wires on a black multi-plug.
207 - 2005		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
308 - 2008		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
308 - 2014	NEW	YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
407 - 2001		YES	YES	YES	YES	CAN H = WHITE CAN LO = GREY	Remove the lower passenger side under panel. The CAN wires are located at the BSI module. The CAN wiring is a twisted pair of wires on black multi-plug.
508 - 2012		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14 or (No. 10 and No. 13) rear at the audio Quadlock
807 - 2003		YES	YES	YES	YES	CAN H = Pin 6 - WHITE CAN LO = Pin 14 - PURPLE	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14.
2008 - 2009	NEW	YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed and reverse signal
3008 - 2009		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed and reverse signal
4007 - 2007		YES	YES	YES	YES	CAN H = GREEN (behind speedometer) ORANGE CAN LO = PINK (behind speedometer) WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector WHITE 20-PIN behind the radio. CAN HIGH No. ORANGE and CAN LOW No. 16 WHITE.
5008 - 2016		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
Bowar - 2007		YES	YES	YES	YES	CAN H = BLUE CAN LO = WHITE	Connector BLUE 20-pin located at rear of fuse box. Position (H and L) No. 6 and No. 5 or to the ISO radio connector.
Biopar - 2008		YES	YES	YES	YES	CAN H = GREEN CAN LO = WHITE	Connected to connector OBD on left underneath steering column. Position (H and L) No. 1 and No. 9 or (No. 6 and No. 14)
Exeent - 2007		YES	YES	YES	YES	CAN H = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L) No. 6 and No. 14 or (No. 10 and No. 13) rear at the audio Quadlock
Partner - 2003		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
Partner - 2005		YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
Partner - 2008	NEW	YES	YES	YES	YES	CAN H = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No. 13, rear at the audio quadlock connector. Position (H and L) No. 6 and No. 14 or OBDII connector only for speed signal
Porsche							
Boxster - 2000		YES	YES	YES	YES	CAN H = WHITE - BLUE CAN LO = WHITE / GREY	Remove the vehicle speedometer assembly. The CAN wires are located at the connector plugs. The CAN bus wiring is a twisted pair of wires at the GREEN plug.
Boxster - 2004		YES	YES	YES	YES	CAN H = YELLOW CAN LO = BLACK	Remove the drivers side kicktrim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.
911 - 2004		YES	YES	YES	YES	CAN H = YELLOW CAN LO = BLACK	Remove the drivers side kicktrim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.
Cayenne - 2003		YES	YES	YES	YES	CAN H = ORANGE / GREEN CAN LO = ORANGE - BROWN	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires.
Cayenne - 2016	NEW	YES	YES	YES	YES	CAN H = ORANGE - BROWN CAN LO = ORANGE - BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connector plugs. The CAN bus wiring is a twisted pair of wires.
Cayman - 2005		YES	YES	YES	YES	CAN H = YELLOW CAN LO = BLACK	Remove the drivers side kicktrim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.

MagicSpeed CB1200 Application & Functionality: 03-2017 SW:14-30

Manufacturer	Modell	Note	Speed	Ignition	Reverse	Wire connections	Position
Renault							
Caplar	2013	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 4	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Clio	2007		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Clio	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Espace	2003		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Espace	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Kadjar	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Kangoo	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Koleos	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Laguna III	2005		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 4	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14
Laguna III	2008		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under the cup holder in the below the centre arm rest. Position (H and L): No. 6 and No. 14
Master	2003		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, behind the drivers side lower dash panel. Position (H and L): No. 6 and No. 14
Master	2005		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove compartment. Position (H and L): No. 6 and No. 14
Magnum	2001		YES	YES	YES	CAN H + PINK CAN/L0 + BROWN / WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. Position (H and L): No. 6 and No. 14
Magnum	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under the radio behind a plastic panel. Position (H and L): No. 6 and No. 14
Modus	2003		YES	YES	YES	CAN H + ORANGE CAN/L0 + BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Scenic	2004		YES	YES	YES	CAN H + BROWN / WHITE CAN/L0 + ORANGE / WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Scenic	2009		YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Talisman	2015	NEW	YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Trafic	2003		YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Trafic	2014	NEW	YES	YES	YES	CAN H + PURPLE / RED CAN/L0 + WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Van Scenic	2002		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14
Wind	2010		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove box. Position (H and L): No. 6 and No. 14
Zoe	2013		YES	YES	YES	CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, inside the glove box. Position (H and L): No. 6 and No. 14
Rover							
75 / MG ZT	2000		YES			CAN H + YELLOW / BLACK CAN/L0 + YELLOW / BLACK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
75 (V6)	2000		YES			CAN H + YELLOW / BLACK CAN/L0 + YELLOW / BLACK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Saab							
93	2006		YES	YES	YES	CAN H + GREEN CAN/L0 + CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
95	2008		YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Remove the vehicle Speed Box. The CAN wires are located at the Left Hand Main Loom. Position (H and L): No. 6 and No. 14
95	2010		YES	YES	YES	CAN H + GREEN / OBD Pin 1 CAN/L0 + BLACK / OBD Pin 4	The CAN wires are available at the OBD connector under the drivers dash. Position (H and L): No. 6 and No. 14
97	2008		YES	YES	YES	CAN H + GREEN CAN/L0 + CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D. Or Position (H and L): No. 6 and No. 14.
Scania							
R570	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
R480	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
Seat							
Athenea	2000		YES	YES	YES	CAN H + ORANGE / BLACK or ORANGE / GREEN CAN/L0 + ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
Athenea	2010	NEW	YES	YES	YES	CAN H + ORANGE / BLACK or ORANGE / GREEN CAN/L0 + ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
Altea	2004		YES	YES	YES	CAN H + YELLOW CAN/L0 + BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
Altea	2008		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Altea	2011		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Exeo	2009		YES	YES	YES	CAN HIGH ORANGE-GREEN CAN/LOW ORANGE-BROWN	Connector GREY/VIOLET 32 pin connector connected to Black control unit (located underneath dashboard drivers side). Position (H and L): No. 13 and No. 12
Ibiza	2003		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin (marked X32) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Ibiza	2010		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Leon	2004		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) the connector is located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Leon	2011		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Mi	2012	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector Fuses behind the radio in the WHITE connector on main unit, the connector is located the lower drivers side under panel.
Skoda							
Octigo	2012		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X32) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Fabia	2002		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X32) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Fabia	2010		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower drivers side under panel.
Fabia	2014	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector Fuses behind the radio in the WHITE connector on main unit, the connector is located the lower drivers side under panel.
Octavia	2005		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 12 pin (marked Q) the connector is located the lower drivers side under panel. Position (H and L): No. 6 and No. 7.
Octavia II	2009		YES	YES	YES	CAN H + ORANGE / GREEN or ORANGE / PURPLE CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Octavia III	2013		YES	(YES)	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin the connector is located the lower drivers side under panel Position (H and L): No. 8 and No. 7. Also found the wiring harness coming from the driver door grommet.
Roomster	2009		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X32) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Supabe	2008		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 18 pin (marked X32) the connector is located the lower drivers side under panel. Position (H and L): No. 12 and No. 9.
Supabe	2015	NEW	YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BLACK 19 pin the connector is located the lower drivers side under panel Position (H and L): No. 8 and No. 7. Also found the wiring harness coming from the driver door grommet.
Yeti	2009		YES	YES	YES	CAN H + ORANGE / GREEN CAN/L0 + ORANGE / BROWN	Connector BROWN 52 pin the connector is located the lower drivers side under panel. Position (H and L): No. 15 and No. 16
Smart							
FourTwo	2007		YES	YES	YES	CAN H + GREEN / WHITE CAN/L0 + GREEN	Remove the vehicle audio unit. The CAN wires are located in the loom running vertical towards the heater panel at the top of the dash. The CAN bus wiring is a twisted pair of wires, coloured as below.
Stangvevo							
Adyon	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Korando	2010		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Rodiux	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Subaru							
Forester	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Impreza	2008		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Legacy	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Outback	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
XV	2012		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Suzuki							
Alto	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Grand Vitara	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
S. Cross	2014		YES	YES	YES	CAN H + RED CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Splach	2009		YES	YES	YES	CAN H + RED/BLACK CAN/L0 + WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Swift	2005		YES	YES	YES	CAN H + RED CAN/L0 + WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Swift	2010	NEW	YES	YES	YES	CAN H + RED CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
SX4	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vitara	2015	NEW	YES	YES	YES	CAN H + RED CAN/L0 + Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Tesla							
Model S	2013	NEW	YES	YES	YES	CAN H + PURPLE/WHITE CAN/L0 + PURPLE	Undo the under panel / pocket trim below the central display unit and located the white connector.
Toyota							
Avenis	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Auris	2007		YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Auris	2013	NEW	YES	YES	YES	CAN H + GREEN CAN/L0 + WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
BB	2007		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, near the centre console under drivers side dash. Position (H and L): No. 6 and No. 14
CHR	2016	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever. Position (H and L): No. 6 and No. 14
Estima	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 6	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever. Position (H and L): No. 6 and No. 14
HILLUX	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Land Cruiser	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prado	2005		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prado	2009		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Prado	2015	NEW	YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
RAV4	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans S	2011		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans	2006		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 6	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
Vans	2011		YES	YES	YES	CAN H + Pin 6 CAN/L0 + Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14

MagicSpeed CB1200 Application & Functionality: 03-2017 SW:14-30

Manufacturer	Model	Note	Speed	Ignition	Reverse	Wire connections	Position
Volkswagen							
	Amarok - 2011			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom WHITE connector 73 points near the steering column. The CAN may also be available at the audio Quattrolock connector
	Beetle - 1999			YES	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Beetle - 2004			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Beetle - 2012			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom WHITE connector 73 points near the steering column. The CAN may also be available at the audio Quattrolock connector
	Caddy - 2005			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Caddy - 2010			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Caddy - 2016	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Caravelle - 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Ceater - 2008			YES (YES*)	AUTO	CAN H = BROWN / RED CAN L0 = BROWN	Remove the lower driver side panel. The CAN wires are located in connector connector wires. The CAN bus wires are twisted pair of wires.
	Ceater - 2014	NEW		YES (YES*)	AUTO	CAN H = BROWN / RED CAN L0 = BROWN	Remove the lower driver side panel. The CAN wires are located in connector connector wires. The CAN bus wires are twisted pair of wires.
	Eos - 2008			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf V - 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf VI - 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Golf VII - 2013			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Golf Plus - 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf Plus - 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Jetta - 2012	NEW		YES (YES*)	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires.
	Passat - 2002			YES (YES*)	YES	CAN H = ORANGE / BLACK CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires.
	Passat - 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Passat - 2011			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 15 and Nr. 16.
	Passat - 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Polo - 2005			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 18 pin (marked E2) the connector is located the lower driverside under panel Position (H and L): Nr. 12 and Nr. 9.
	Polo - 2010			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector WHITE controller box, the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Polo - 2015	NEW		YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 73 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Routan - 2009			YES (YES*)	YES	CAN H = WHITE / GREY CAN L0 = WHITE / ORANGE	The CAN bus wiring is a twisted pair of wires, located at the radio wiring connector. Remove the radio panel (stepped) and under the radio for access.
	Scirocco - 2009			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Sharan - 2002			YES	YES	CAN H = ORANGE / BLACK or ORANGE CAN L0 = ORANGE / GREEN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
	Sharan - 2010			YES	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	The CAN wires are located in the steering column loom. The CAN wiring is a twisted pair.
	Tiguan - 2007 (9009)			YES (YES*)	YES	CAN H = ORANGE / PURPLE CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Tiguan - 2016	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 13 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Touareg - 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires.
	Touareg - 2011			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Remove the lower driverside under panel. The CAN wires are a twisted pair located in the main loom 'C' BROWN connector 16 points near the steering column.
	Touareg - 2014			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 12 pin (marked G) the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Touareg - 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BLACK 73 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7. Also found the wiring harness coming from the driver door grommet.
	Transporter - 2004			YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector BROWN 12 pin the connector is located the lower driverside under panel Position (H and L): Nr. 8 and Nr. 7.
	Transporter - 2015	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector Fuses behind the radio or the WHITE connector on main unit, the connector is located the lower driverside under panel.
	Up - 2012	NEW		YES (YES*)	YES	CAN H = ORANGE / GREEN CAN L0 = ORANGE / BROWN	Connector Fuses behind the radio or the WHITE connector on main unit, the connector is located the lower driverside under panel.
Volvo							
	C30 - 2007			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	C70 - 2001			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S40 - 2005			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S60 - 2001			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S60 - 2010			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	S90 - 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V40 - 2012	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V50 - 2005			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V70 - 2000			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	V70 - 2011			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): Nr. 3 and Nr. 11.
	V90 - 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): Nr. 3 and Nr. 11.
	X300 - 2010			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 - 2000			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 - 2011			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 - 2009			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
	X30 - 2016	NEW		YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.
Volvo Truck							
	FM12 - 2002			YES	YES	CAN H = Pin 3 CAN L0 = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): Nr. 3 and Nr. 11.

Column IGNITION
For the vehicle applications shown with a YES* in the ignition column, the system activates when the ignition is turned on and will remain live for 30 seconds.

Column REVERSE
The meaning of MANC or AUTO* in the column CLUTCH.
The meaning of INC* in the clutch column is the clutch signal is available only on vehicles equipped with OEM cruise control.